

## BATERIE TRX PRO ACER 7800MAH



Cena celkem:	<b>1 218 Kč</b> <b>(bez DPH: 1 007 Kč)</b>
Běžná cena:	<b>1 340 Kč</b>
Ušetříte:	<b>122 Kč</b>
Kód zboží:	BATRX8140
Part No.:	TRX-AS10D31 XH
Záruka:	24 měs.
Stav:	Nové zboží

## Popis

### TRX AS10D31 XH

#### ZÁKLADNÍ SPECIFIKACE

**Technologie baterie:** Li-Ion

**Napětí:** 10,8 V, 11,1V

**Kapacita:** 7800 mAh

**Baterie je záměnná s těmito produktovými čísly:**

AS10D, AS10D3E, AS10D31, AS10D41, AS10D5E, AS10D51, AS10D61, AS10D7E, AS10D71, AS10D73, AS10D75, AS10D81

BT.0060G.001, BT.00603.111, BT.00603.117, BT.00603.124, BT.00603.129, BT.00604.049, BT.00605.062, BT.00605.065, BT.00605.072, BT.00606.008, BT.00607.125, BT.00607.126, BT.00607.127, BT.00607.130

LC.BTP0A.015, LC.BTP00.123, 31NR19/65-2, 31CR19/652, 31CR19/65-2, 31CR19/66-2, AK.006BT.075, AK.006BT.080

**Baterie je kompatibilní s těmito modely:**

ACER  
Aspire AS5253  
Aspire E1  
Aspire E1-421  
Aspire E1-431  
Aspire E1-471  
Aspire E1-471G

Aspire E1-521  
Aspire E1-531  
Aspire E1-571  
Aspire V3  
Aspire V3-471  
Aspire V3-471G  
Aspire V3-551  
Aspire V3-551G  
Aspire V3-571  
Aspire V3-571G  
Aspire V3-731  
Aspire V3-771  
Aspire V3-771G  
Aspire 4250  
Aspire 4250G  
Aspire 4250Z  
Aspire 4251  
Aspire 4251G  
Aspire 4251Z  
Aspire 4252  
Aspire 4252G  
Aspire 4252Z  
Aspire 4253  
Aspire 4253G  
Aspire 4333  
Aspire 4339  
Aspire 4349  
Aspire 4350  
Aspire 4350G  
Aspire 4352  
Aspire 4551  
Aspire 4551G  
Aspire 4551P  
Aspire 4552  
Aspire 4552G  
Aspire 4552-5078  
Aspire 4560  
Aspire 4560G  
Aspire 4733Z  
Aspire 4738  
Aspire 4738G  
Aspire 4738Z  
Aspire 4738ZG  
Aspire 4739  
Aspire 4739Z  
Aspire 4741  
Aspire 4741G  
Aspire 4741Z  
Aspire 4741ZG  
Aspire 4743  
Aspire 4743G  
Aspire 4743Z  
Aspire 4743ZG  
Aspire 4749  
Aspire 4749Z  
Aspire 4750  
Aspire 4750G  
Aspire 4750Z  
Aspire 4750ZG  
Aspire 4752  
Aspire 4752G  
Aspire 4752Z

Aspire 4752ZG  
Aspire 4755  
Aspire 4755G  
Aspire 4755ZG  
Aspire 4771  
Aspire 4771G  
Aspire 4771Z  
Aspire 5250  
Aspire 5251  
Aspire 5252  
Aspire 5253  
Aspire 5253G  
Aspire 5333  
Aspire 5336  
Aspire 5342  
Aspire 5349  
Aspire 5350  
Aspire 5551  
Aspire 5551G  
Aspire 5552  
Aspire 5552G  
Aspire 5560G  
Aspire 5733  
Aspire 5733Z  
Aspire 5736  
Aspire 5736G  
Aspire 5736Z  
Aspire 5736ZG  
Aspire 5741  
Aspire 5741G  
Aspire 5741Z  
Aspire 5741ZG  
Aspire 5742  
Aspire 5742G  
Aspire 5742Z  
Aspire 5742ZG  
Aspire 5749  
Aspire 5749Z  
Aspire 5750  
Aspire 5750G  
Aspire 5750TG  
Aspire 5750Z  
Aspire 5750ZG  
Aspire 5755  
Aspire 5755G  
Aspire 5755Z  
Aspire 5755ZG  
Aspire 7251  
Aspire 7551  
Aspire 7551G  
Aspire 7551Z  
Aspire 7551ZG  
Aspire 7552G  
Aspire 7560  
Aspire 7560G  
Aspire 7741  
Aspire 7741G  
Aspire 7741Z  
Aspire 7741ZG  
Aspire 7750  
Aspire 7750G  
Aspire 7750Z

Aspire 7750ZG  
TravelMate P243  
TravelMate P243-M  
TravelMate P243-MG  
TravelMate P453  
Travelmate P453-M  
TravelMate P453-MG  
TravelMate TM5740  
TravelMate TM5742  
TravelMate 4370  
TravelMate 4740  
TravelMate 4740G  
TravelMate 4740Z  
TravelMate 4740ZG  
TravelMate 4750  
TravelMate 4750G  
TravelMate 4750Z  
TravelMate 4750ZG  
TravelMate 5335  
TravelMate 5335G  
TravelMate 5335Z  
TravelMate 5340  
TravelMate 5340G  
Travelmate 5344  
TravelMate 5360  
TravelMate 5360G  
TravelMate 5542  
TravelMate 5542G  
Travelmate 5735  
TravelMate 5735G  
TravelMate 5735Z  
Travelmate 5735ZG  
TravelMate 5740  
TravelMate 5740G  
Travelmate 5740Z  
TravelMate 5740ZG  
TravelMate 5742  
TravelMate 5742G  
TravelMate 5742Z  
TravelMate 5742ZG  
TravelMate 5744  
TravelMate 5744G  
TravelMate 5744Z  
TravelMate 5760  
Travelmate 5760G  
TravelMate 6495  
TravelMate 6495G  
TravelMate 6495T  
TravelMate 6495TG  
TravelMate 6595  
TravelMate 6595G  
TravelMate 6595T  
TravelMate 6595TG  
TravelMate 7340  
TravelMate 7740  
TravelMate 7740G  
TravelMate 7740Z  
TravelMate 7740ZG  
TravelMate 7750G  
TravelMate 7750Z  
Travelmate 7750ZG  
TravelMate 8472

TravelMate 8472 HF  
TravelMate 8472G  
TravelMate 8472G HF  
TravelMate 8472T  
TravelMate 8472T HF  
TravelMate 8472TG  
TravelMate 8472TG HF  
TravelMate 8473  
TravelMate 8473G  
TravelMate 8473T  
TravelMate 8473TG  
TravelMate 8572  
TravelMate 8572G  
TravelMate 8572T  
TravelMate 8572T HF  
TravelMate 8572TG  
TravelMate 8573  
TravelMate 8573G  
TravelMate 8573T  
TravelMate 8573TG

#### EMACHINES

D440, D442, D443, D582, D642, D728, D730, D732, E440, E442, E529, E640, E642, E729, E732, G640, G730

#### GATEWAY

NS41I, NS51I, NV49C, NV49C13C, NV49xx, NV50A, NV51B, NV53, NV53A, NV53A11u, NV55C, NV59C NV73A, NV79, NV79C

#### PACKARD BELL

EasyNote LS11, EasyNote LS13, EasyNote LS44, EasyNote LV11, EasyNote LV44, EasyNote NM85, EasyNote NM86, EasyNote NM87, EasyNote NM98, EasyNote TE11, EasyNote TK36, EasyNote TK37, EasyNote TK81, EasyNote TK83, EasyNote TK85, EasyNote TK87, EasyNote TM98, EasyNote TS11, EasyNote TS13, EasyNote TV11, EasyNote TV43, EasyNote TV43HC, EasyNote TV44